

Auto Configuration Check!

LOXONE

General

Network, Remote Connect and Online services

- Is Miniserver registered in Partner Portal?
- Configure local network for Miniserver, Audioserver and Intercom
- Register Weather/Caller service
- Set phone numbers in the Caller Service

Project

- Proper Project and Miniserver naming
- Author and Customer data
- Geo-Coordinates

Diagnostics

- Health Check
- Project Validation

User and Permissions

- User and User Groups rights
- Users assigned to the corresponding groups
- User passwords
- User Interface passwords
- Authentication (PIN code, NFC tag)

Logic

Lighting

- Proper naming of light circuits and light groups for the customer
- Adjustment of basic parameters: Met, Moet, Pto and Brt
- Choose between presence or motion
- If is needed, add an additional Night mode and set Night mood (e.g. for children's bedrooms)
- Add logic to block ceiling presence sensor in Night mode in bedrooms
- Check if the correct brightness sensor has been connected.

Shading

- Proper naming for customer
- Is the window contact connected? If it requires it is negated?
- If relays are used, are the Opd and Cld parameters set?
- All important parameters for automatic shading are set?
(Type, Dir, Dts, Dte, Sw, Sd, Spm, Bld, Bldo, Spe and Wap)
- If needed, adjust parameters for Frost Protection and Storm Protection in Central

Climate

- Check if the correct Temperature Sensor has been connected.
- Adjust Intelligent Room Controller and Heating and Cooling Controller assignment (enable heating - cooling)
- Is the window contact connected? If it requires it is negated?
- Are the valve actuators connected to the correct outputs (H1, C1, HC1, H2, C2,...)
- Are the Intelligent Room Controllers correctly assigned to the Heating and Cooling Controller and Flow Temperature Controller function blocks?
- Add specific logic for your HVAC

Presence detection

- Adjust Overrun Time presence and Overrun Duration Following Motion on Presence Sensors
- Adjust Presence extend time on Presence function block
- Adjust Volume Thresholds on Presence sensors

Audio

- Adjust Stereo/Downmix Stereo programming if needed
- Set the correct speaker impedance
- Create Audio Player Fixed Group if it's needed

Burglar alarm

- Check selected sensors and actuators in Alarm function block
- If needed, adjust the parameters of the arming delay and the delay of the individual alarm levels.

Central Fire and Water Alarm System

- Check selected sensors
- If an anthracite Touch is exposed to direct sunlight, its overheating can trigger a fire alarm, in this case adjust the Max θ parameter or remove the Touch from the Central Fire Alarm block.

App

- Set the corresponding room icons, ratings and favourites
- If needed adapt the corresponding function block icons, ratings and favourites.